Blast

Operating Instructions

Height adjustable backrest on a ratchet mechanism - hold the back and lift to raise, a click will be heard as the next level is reached.

To lower, fully raise the backrest to the highest position, once reached the back will then drop down to the lowest position

Arm rest height adjustment - pull button up to raise or lower the height of the arm

Seat resistance tension adjustment – rotate as shown on the handle to increase or decrease tension

Gas lift height adjustment – pull lever upwards (without weight on seat) to raise seat height. To lower seat height, remain seated and pull lever upwards

Seat Slide adjustment, (optional)
pull button up to move seat back or forward

Synchro Mechanism release – to adjust the back and seat angle – rotate to adjust. Anti clockwise to release, clockwise to lock.

Once the control has been placed into the release position the chair will not move until the user has rested against the seat back. A click will be heard and the seat will then move freely to obtain the correct position. Once the position has been found rotate the dial to the locked position.

Silver base is an optional extra

Unit 1 Bridge Trading Centre
High Street, Wordsley, West Midlands
DY8 5SD
t: 01384-480030 e: sales@chairclinic.co.uk www.chairclinic.co.uk